

**BONGSHIN<sup>®</sup>**



## **OPERATIONAL MANUAL**

---



## **BS-270**

---

### **LOAD LIMITER**

---

# CONTENTS

|                                       |           |
|---------------------------------------|-----------|
| <b>INTRODUCTIONS . . . . .</b>        | <b>2</b>  |
| <b>FEATURES . . . . .</b>             | <b>3</b>  |
| <b>TECHNICAL SPECIFICATION . .</b>    | <b>4</b>  |
| <b>DIMENSIONS . . . . .</b>           | <b>5</b>  |
| <b>FRONT PANEL . . . . .</b>          | <b>6</b>  |
| <b>CONNECTION . . . . .</b>           | <b>8</b>  |
| <b>CALIBRATION MODE . . . . .</b>     | <b>11</b> |
| <b>ZERO CALIBRATION . . . . .</b>     | <b>18</b> |
| <b>LOW, HIGH SET . . . . .</b>        | <b>20</b> |
| <b>SERIAL INTERFACE . . . . .</b>     | <b>23</b> |
| <b>Analog output (Option) . . . .</b> | <b>25</b> |
| <b>Error Message</b>                  |           |
| <b>and Trouble Shooting . . . .</b>   | <b>30</b> |

# INTRODUCTIONS

## 1. INTRODUCTION

Thank you very much for your purchasing BONGSHIN Digital Weighing LOAD LIMITER of **BS-270**.

This Instruction Manual will lead you to use **BS-270** with top reliability, High speed, high accuracy.

**BS-270** series are over load limiters for cranes, lifts and elevators and so reliable because of using strain gage type-load cell.

They are easy to install because of their small size and built-in digital monitor. Digital Weighing Indicator amplifying the analog output from a load Cell, converting the analog signal to digital data and then displaying this data

As a weight reading and is designed for flawless performance in your demanding

Before using, It is recommended that you read this manual carefully so you may use this device to its full potential.

## 2. PRECAUTIONS

- Place the indicator on a flat and stable surface.
- Do not severely press because the light pressing of keys can incite the operation.
- Do not subject the scale to sudden temperature changes.  
Operating temperature :  $-10^{\circ}\text{C} \sim +40^{\circ}\text{C}$
- Keep the scale away from strong EMI noises may cause incorrect weight readings.
- Keep the main body from rain and keep in dry area.
- Do not use inflammable materials in cleaning.

# FEATURES

## 1. Features

- Dual set points relay output.
- 5 digit high brightness LED display.
- Wall mount type enclosure (splash proof)
- Appropriate for weight and measurement system.
- Easy operation and various options.
- Simple full digital calibration.
- Watchdog circuitry (system restoration)
- Weight Back-up (power on actual weight)


## 2. Main Function

- RS-232C standard
- User can set the max. weight which users want to and division at one's disposal.


## TECHNICAL SPECIFICATION

|                                  |                 |   |
|----------------------------------|-----------------|---|
| <b>Analog signal Input range</b> |                 | +1mV ~ +34mV  |
| <b>Non-linearity</b>             |                 | 0.01% F.S. max.   |
| <b>Max. Display resolution</b>   |                 | 1/10,000  |
| <b>Min. Input sensitivity</b>    |                 | 0.3 $\mu$ V/Digit   |
| <b>Temperature Drift</b>         |                 | Zero drift : $\pm 0.2 \mu\text{V}/^{\circ}\text{C}$ RTI max.<br>Span drift : 20ppm/ $^{\circ}\text{C}$ max. |
| <b>Load cell Excitation</b>      |                 | DC 10V, 300mA<br>350ohm x 4 load cell   |
| <b>Input Noise</b>               |                 | $\pm 0.3 \mu\text{V}$ p.p or less   |
| <b>Input Impedance</b>           |                 | 10 $M\Omega$ (Min.)   |
| <b>A/D converter</b>             |                 | 24bit Sigma-Delta system  |
| <b>A/D internal resolution</b>   |                 | Approximately 200,000 counts  |
| <b>A/D conversion speed</b>      |                 | 10 times/sec  |
| <b>Display</b>                   |                 | 7 Segment LED,<br>5 Digits, 13mm(Height)  |
| <b>Polarity Indication(-)</b>    |                 | "-" minus sign  |
| <b>Annunciators</b>              |                 | Low(Alarm), High(Overload)  |
| <b>Display increments</b>        |                 | 1, 2, 5, 10, 20, 50 selectable  |
| <b>Decimal Points</b>            |                 | Selectable to any points  |
| <b>Operating Voltage</b>         |                 | AC 110/220V, 50/60Hz  |
| <b>Power consumption</b>         |                 | Approx. 10 VA   |
| <b>Operating temperature</b>     |                 | -10 $^{\circ}\text{C}$ ~ +40 $^{\circ}\text{C}$   |
| <b>Output</b>                    | <b>Standard</b> | RS-232C serial output   |
|                                  | <b>Options</b>  | 1) DC 0~10V (Voltage output)<br>2) DC 4~20mA (Current output)   |
| <b>Weight</b>                    |                 | Approx. 3.0kg   |

# DIMENSIONS



## Front Panel



### 1. Display Lamp ( )

 **LOW lamp** : It will lamp when 1st set point(LOW) control works.

 **HIGH lamp** : It will lamp when 2nd set point(HIGH) control works.

### 2. Keyboard



Change the digit of the set value.

Move to the right by 1 place.

Usage—input the numeric value in CAL mode.



Available keys instead of numeric keys.

Change the set value

Increases the first place value to 1.



■ **CAL mode** : Switch to select one of the modes cycles.



■ **CAL mode** :

Change the digit of the set value.

Move to the right by 1 place.

■ **LOCK mode** : LOW Relay Range identify.



■ **CAL mode** :

Available keys instead of numeric keys.

Change the set value

Increases the first place value to 1.

■ **LOCK mode** : HIGH Relay Range identify.




■ **CAL mode** : Store current condition and exit.

■ **ON, OFF** : POWER ON, OFF

■ **Dip slide switch** : CALIBRATION mode


SW ON : Shift to calibration mode.

Turn sw off after calibration, It returns to weighing mode.





## CONNECTION



■ **AC IN** : Available to change AC110/220V with multiple.

Before setting up, please confirm the power voltage.

Please change the connect terminal of 110V/220V after opening the cover

If you need to change. (It was settled with AC220V at the first)

Use a stable power supply AC110/220V  $\pm 10\%$ , 50/60Hz

**FUSE** : Please use the standard approved .

FUSE AC250V, 0.5A (a glass tube with small type)


■ **OUT-PUT** : N.O, COM, N.C(LOW) / N.C, COM, N.O(HIGH)

Connect between COM terminal and N.O/N.C terminal

With the earth of no electric power.

Please use the output data For a signal only, don't use it for working.

Max earth capacity : AC250V / 0.5A



|     |       |
|-----|-------|
| OFF | open  |
| ON  | short |

■ **LOAD CELL** : Please connect the indicator connector with the wire of load cell according to the color.




SHLD EXC- SIG- SIG+ EXC+



LOAD CELL

| Pin no. | SIGNAL |   |
|---------|--------|---|
| 1       | SHLD   | SHIELD  |
| 2       | EXC-   | Load cell Input Voltage (-) : <b>EXC- (white)</b> |
| 3       | SIG-   | Load cell output (-) : <b>SIG- (blue)</b>         |
| 4       | SIG+   | Load cell output (+) : <b>SIG+ (green)</b>        |
| 5       | EXC+   | Load cell Input Voltage (+) : <b>EXC+ (red)</b>   |




※ Because wire color may be different according to a manufacture and load cell models. Please refer for the data sheet of load cell.


The wire color of load cell according to a manufactures.

|               | 1      | 2     | 3     | 4     | 5     |
|---------------|--------|-------|-------|-------|-------|
|               | SHIELD | EXC-  | SIG-  | SIG+  | EXC+  |
| BONGSHIN      | SHIELD | WHITE | BLUE  | GREEN | RED   |
| CAS, TMI, AND | SHIELD | WHITE | BLUE  | GREEN | RED   |
| BLH           | YELLOW | BLACK | RED   | WHITE | GREEN |
| INTERFACE     | SHIELD | BLACK | WHITE | GREEN | RED   |
| KYOWA         | SHIELD | BLACK | WHITE | GREEN | RED   |
| P.T.          | SHIELD | BLACK | WHITE | GREEN | RED   |
| SHOWA         | SHIELD | BLUE  | BLACK | WHITE | RED   |
| SHINKOH       | SHIELD | BLACK | WHITE | GREEN | RED   |
| TML           | SHIELD | BLACK | GREEN | WHITE | RED   |
| TFAC          | YELLOW | BLUE  | BLACK | WHITE | RED   |
| HUNTLEIGH     | SHIELD | BLACK | WHITE | RED   | GREEN |

■ **RS-232C Port (Standard)** : Serial interface port.  
(computer, printer)



■ **Analog Output (Option)** : Analog Output 0 ~10V, 4~20mA  
(PLC Interface)




# Calibration mode

## 1. How to enter CAL mode

Slid switch usage

### ■ Dip slide SW CALB. – CALIBRATION Mode



Pressing



the key and set mode start.

## 2. Key Usage



■ **CAL mode** : Switch to select one of the modes cycles.



■ **CAL mode** :

Change the digit of the set value.

Move to the right by 1 place.



■ **CAL mode** :

Available keys instead of numeric keys.

Change the set value

Increases the first place value to 1.



■ **CAL mode** : Store current condition and exit.

### 3. Calibration Menu (Step 1 ~ Step 8)

- Step 1 : Minimum Division Set
- Step 2 : Zero Calibration
- Step 3 : Decimal Point Adjustment
- Step 4 : Setting Weight in span calibration
- Step 5 : Maximum Capacity Set
- Step 6 : LOW(Alarm) Weight Set
- Step 7 : HIGH(Overload) Weight Set
- Step 8 : END

#### ■ Step 1

– Function : **Minimum Division Set**

Range → 1, 2, 5, 10, 20, 50






A step to set up a division value.

"15" means "Division" and "xx" means a division capable of displaying.

Also this value will be displayed as 1–2–5–10–20–50 by each key.

A step to set up a Decimal point is Function mode.

So, it will be go to the next step recording the position.



| Key   | Display   | Description   |
|---|---|---|
|  : mode                           |  | 0.01 ton<br>(Decimal point :0.00)   |
|  :move into                      |   | 1 : 1,2,3,4,5…  |
|  : increase                      |   | 2 : 2,4,6,8,10…   |
|  : Store and move into next menu |   | 5 : 5,10,15,20,25…<br>10 : 10,20,30,40,50…<br>20 : 20,40,60,80,100…<br>50 : 50,100,150,200,250… |

REF 1. The minimum division means the value of one division.

REF 2. External resolution is obtained by division the min. division by the maximum capacity. Set the resolution to be within 1/10,000.

## ■ Step 2





– Function : **Zero Calibration**

| Key   | Display   | Description  |
|---|---|--|
| <br>Zero calibration<br>and move into<br>next menu |  | Unload the tray and press “ENT”<br><br><b>key</b> Under zero calibration<br><br>Zero calibration is completed. |

REF 1. If zero calibration is done without any error, “18888” message is displayed and program moves into Step 3 automatically.

## ■ Step 3








– Function : **Decimal Point Adjustment**

| Key  | Display   | Description  |
|--|---|--|
|  : move into<br><br> : Shift of<br>decimal<br>point<br><br> : Store and<br>move into<br>next menu |  | 18888 : 0<br>1888.8 : 0.0<br><b>188.88 : 0.00</b><br>18.888 : 0.000<br>1.8888 : 0.0000 |

## ■ Step 4

– Function : **Setting Weight In Span Calibration**

Range → 1~ 99,999

| Key  | Display   | Description  |
|--|---|--|
|  : move into<br> : Increase<br> : Shift of digit<br> : Store and move into next menu |  | Setting Weight<br>20.00ton<br>Load the weight which was set in and press “ENT” key.<br>Under span calibration<br>Example : 20.00 ton setting<br><br>5.00 ton setting<br> |

REF 1. The weight shall be within the range of 10%~100% of maximum weight.






REF 2. The setting weight must be over the range of 10% of maximum weight.

REF 3. The setting weight over the maximum capacity.

## ■ Step 5

– Function : **Maximum Capacity Set**

Range → 1 ~ 99,999






| Key  | Display   | Description                       |
|--|---|-----------------------------------|
|  : move into<br> : Increase<br> : Shift of digit<br> : Store and move into next menu |  | Maximum capacity<br><br>20.00 ton |

REF 1. The maximum capacity means the maximum weight that scale can measure.

## ■ Step 6

– Function : **LOW (Alarm) weight Set**

Range → 1 ~ 99,999






| Key  | Display   | Description                            |
|--|---|--|
|  : move into<br> : Increase<br> : Shift of digit<br> : Store and move into next menu |  | LOW(Alarm) weight set<br><br>20.00 ton |



## ■ Step 7

– Function : **HIGH (Overload) weight Set**

Range → 1 ~ 99,999

| Key  | Display   | Description                                |
|--|---|--|
|  : move into<br> : Increase<br> : Shift of digit<br> : Store and move into next menu |  | HIGH(Overload) weight set<br><br>22.00 ton |



## ■ Step 8

– Function : **END**

The "Good" message is displayed in 8 step,  
all span adjustment is end.

Press “ENT” key after put down of span standard weight on the crane.


The indicator will enter into user's weighing mode.

| Key   | Display   | Description |
|---|---|-------------|
|  : Store and move into weighing mode |  | END         |

## 4. How to enter Weighing mode

Slid switch usage

### ■ Dip slide SW LOCK – Weighing Mode




# ZERO Calibration

## 1. How to enter CAL mode

Slid switch usage

### ■ Dip slide SW CALB. – CALIBRATION Mode






Pressing



the key and set mode start.

## 2. ZERO Calibration

### ■ Step 1

| Key  | Display   | Description   |
|--|---|---|
|  : mode<br><br> :<br><br>Zero calibration and move into next menu |  | Each times are press the “F” mode key which is changed preset conditions as followed.<br><br>Unload the tray and press “ENT”<br><br><b>key</b> Under zero calibration<br><br>Zero calibration is completed. |




REF 1. If zero calibration is done without any error, “18888” message is displayed and program moves into Step 1 automatically.

## ■ Step 2

– Function : **END**

The "Good" message is displayed in 2 step,  
all zero adjustment is end.


The indicator will enter into user's weighing mode.

| Key   | Display   | Description   |
|---|---|---|
|  : mode<br><br> : Store and move into weighing mode |  | Each times are press the<br>"F" mode key which is<br>changed preset conditions<br>as followed.<br><br>END |

## 3. How to enter Weighing mode

Slid switch usage

■ Dip slide SW LOCK – Weighing Mode





LOW(Alarm), HIGH(Overload) SET

1. How to enter CAL mode

Slid switch usage







■ Dip slide SW CALB. – CALIBRATION Mode



Pressing  the key and set mode start.

2. LOW (Alarm) weight setting







Range → 1 ~ 99,999


| Key   | Display  | Description   |
|---|--|---|
|  : mode                            |  | Each times are press the “F” mode key which is changed preset conditions as followed. |
|  : move into                     |  |   |
|  : Increase                      |  |   |
|  : Shift of digit                |  |   |
|  : Store and move into next menu |  |   |
|   |  | LOW(Alarm) weight set<br>20.00 ton  |

REF 1. LOW(Alarm) weight ≤ HIGH(Overload) weight

### 3. HIGH (Overload) weight setting

Range → 1 ~ 99,999

| Key  | Display   | Description  |
|--|---|--|
|  : mode<br> : move into<br> : Increase<br> : Shift of digit<br> : Store and move into next menu |  | <p>Each times are press the "F" mode key which is changed preset conditions as followed.</p> <p>HIGH(Overload) weight set</p> <p>22.00 ton</p> |

 REF 1. LOW(Alarm) weight  $\leq$  HIGH(Overload) weight




### 4. How to enter Weighing mode

– Function : **END**

The "Good" message is displayed, all relay adjustment is end.


Press "ENT" key after put down of span standard weight on the crane.

The indicator will enter into user's weighing mode.

| Key   | Display   | Description   |
|---|---|---|
|  : mode<br><br> : Store and move into weighing mode |  | <p>Each times are press the “F” mode key which is changed preset conditions as followed.</p> <p>END</p> |

Slid switch usage


■ **Dip slide SW LOCK – Weighing Mode**







► **RS-232C port connection**



## Analog output (option)

### 1. Voltage (0~10V) Analog Output

- \* The voltage output occurs proportionally the voltage according to the size of a weight  
In 0V ~10V.

#### ■ SPECIFICATION

|                |                |
|----------------|----------------|
| output Voltage | 0 ~ 10V DC out |
| Precision      | Max 1/1000     |
| Min Impedance  | Over 1 kΩ      |


#### ■ Analog Out Standard Weight Selecting.

Analog max out value when weight setup.

The indicator will enter into user's CALB mode.

Slid switch usage

#### ■ Dip slide SW CALB. – CALIBRATION Mode



Pressing



the key and set mode start.

**Dip slide sw** : CALB mode

SW ON (up) : Shift to CALB mode. (calibration mode)

## ■ Maximum Capacity set

Range → 1 ~ 99,999

| Key  | Display | Description                      |
|--|---------|----------------------------------|
| <div>ENT</div> : move into                     |         | Maximum capacity                 |
| <div>LOW</div> : Increase                      |         | 20.00 ton                        |
| <div>HIGH</div> : Shift of digit               |         | example)                         |
| <div>ENT</div> : Store and move into next menu |         | 0.00 ton → 0V<br>20.00 ton → 10V |

REF 1. The maximum capacity means the maximum weight that scale can measure.

## ■ Adjustment



- \* The voltage out is to 0V when the weight is displayed 0 kg in indicator.
- \* The voltage out is to 10V when the weight is displayed max. capacity in indicator.
- \* If analog output is not correct,  
 You can make a fine adjustment with “ZERO” VR(Zero adjustment) and “GAIN” VR(Span adjustment)  
 on analog pc board by multi meter.  
 ( Recommended accuracy : 1/1,000 )

## 2. Electric current (4~20mA) Analog Output

- \* The voltage output occurs proportionally the voltage according to the size of a weight  
In 4mA ~20mA.


### ■ SPECIFICATION


|                |                          |
|----------------|--------------------------|
| output Voltage | 4 ~ 20 mA DC Current out |
| Precision      | Max 1/1000               |
| Min Impedance  | Under 500 Ω              |

### ■ Analog Out Standard Weight Selecting.

Analog max out value when weight setup.  
The indicator will enter into user's CALB mode.  
Slid switch usage

### ■ Dip slide SW CALB. – CALIBRATION Mode



Pressing  the key and set mode start.

**Dip slide sw** : CALB mode

SW ON (up) : Shift to CALB mode. (calibration mode)

## ■ Maximum Capacity set

Range → 1 ~ 99,999

| Key  | Display | Description                          |
|--|---------|--------------------------------------|
| <div>ENT</div> : move into                     |         | Maximum capacity                     |
| <div>LOW</div> : Increase                      |         | 20.00 ton                            |
| <div>HIGH</div> : Shift of digit               |         | example)                             |
| <div>ENT</div> : Store and move into next menu |         | 0.00 ton → 4 mA<br>20.00 ton → 20 mA |

REF 1. The maximum capacity means the maximum weight that scale can measure.

## ■ Adjustment



### \* How to calibrate for output rate between 4mA and 20mA.

The current out is to 4 mA when the weight is displayed 0 kg in indicator.

The current out is to 20 mA when the weight is displayed max. capacity in indicator.

If analog output is not correct,

You can make a fine adjustment with “ZERO” VR(Zero adjustment) and “GAIN” VR(Span adjustment)

On analog pc board by multi meter.




### 3. How to enter Weighing mode

– Function : **END**

The "Good" message is displayed, all relay adjustment is end.


Press **"ENT"** key after put down of span standard weight on the crane.

The indicator will enter into user's weighing mode.

| Key   | Display   | Description  |
|---|---|--|
|  : mode<br><br> : Store and move into weighing mode |  | Each times are press the "F" mode key which is changed preset conditions as followed.<br><br>END |

Slid switch usage

■ **Dip slide SW LOCK – Weighing Mode**



## Error Message and Trouble Shooting

| ERROR   | CAUSE  | A/S  | Reference.   |
|---|--|--|--|
| Waving a weight Value.<br>Appear <b>"no.LC"</b>   | ① Load cell damage<br>② Insulation resistance badness of load cell.<br>③ Weighing part error | ① Checking for Input, Output of load cell. Resistance Value.<br>② Checking Insulation Resistance value of Load cell. | ① Input resistance : about 1130Ω<br>② Output resistance : about 1000Ω<br>③ Insulation Resistance : over100MΩ |
| A. Changing a Weight value,<br>B. Not return to ZERO<br>Appear <b>"Ovr "</b><br>(OVER LOAD) | ① Load cell damage.  | ① Checking Insulation Resistance value of Load cell.<br>(Normal Max 100MΩ or -Ovr-appear)                            |  |
|   | ① Disconnected to Load Cell.   | ① Confirm a connect of Load cell<br>② Checking a single wire Of load cell cable                                      |  |
| Weight (-) changed<br>Appear <b>"-Ovr "</b><br>(OVER LOAD)                                  | ① Load cell output (SIG+,SIG-)changed.   | ① Load cell connector  |  |
| Appear <b>"Ovr"</b> or <b>"-Ovr "</b>   | ① Load cell damage<br>② Connection Error   | ① Load cell damage<br>② Load cell connector  |  |
|   | ① Excess Max weight  | ① Remove excess weight   |  |