

## **OPERATIONAL MANUAL**

---



# **BS-5205**

---

## **DIGITAL INDICATOR**

---

## CONTENTS

|                                    |           |
|------------------------------------|-----------|
| <b>INTRODUCTIONS . . . . .</b>     | <b>2</b>  |
| <b>THE FEATURES OF BS-5205 . .</b> | <b>3</b>  |
| <b>TECHNICAL SPECIFICATION . .</b> | <b>4</b>  |
| <b>DIMENSIONS . . . . .</b>        | <b>6</b>  |
| <b>FRONT PANEL . . . . .</b>       | <b>7</b>  |
| <b>REAR PANEL. . . . .</b>         | <b>10</b> |
| <b>CALIBRATION MODE . . . . .</b>  | <b>12</b> |
| <b>SIMULATION MODE . . . .</b>     | <b>16</b> |
| <b>SET MODE . . . . .</b>          | <b>20</b> |
| <b>SERIAL INTERFACE . . . . .</b>  | <b>25</b> |
| <b>OPTION . . . . .</b>            | <b>30</b> |
| <b>Error Message</b>               |           |
| <b>And Trouble Shooting . . .</b>  | <b>31</b> |

## 1. INTRODUCTION

We greatly appreciate your purchase of the BONGSHIN industrial indicator. These goods perform excellently and exhibit splendid properties through strike tests.

BONGSHIN indicator is delicately designed to coincide with the special requirements of several industrial fields and includes many functions and various external interfaces. Also, it is programmed for the user's convenience and contains help display functions that are easily accessible.

Before using **BS-5205**, It is recommended that you read this manual carefully so you may use this device to its full potential.

## 2. PRECAUTIONS

- Place the indicator on a flat and stable surface.
- Do not severely press because the light pressing of keys can incite the operation.
- Do not subject the scale to sudden temperature changes.  
Operating temperature :  $-10^{\circ}\text{C} \sim 50^{\circ}\text{C}$
- Keep the scale away from strong EMI noises may cause incorrect weight readings.
- Keep the main body from rain and keep in dry area.
- Do not use inflammable materials in cleaning.

# THE FEATURES OF BS-5205

## 1. Features

- Appropriate for weight and measurement system.
- Easy operation and various options.
- Simple full digital calibration.
- Self check & Watch-dog function
- Weight Back-up (power on actual weight)

## 2. Main Function

- Various specification of weight conversion speed.  
(Digital Filter Function)
- Various printer connection. (RS-232C Serial Printer)
- RS-232C Serial Output standard
- User can set the max. weight which users want to and division at one's disposal.

## TECHNICAL SPECIFICATION

### 1. Analog Input & A/D Conversion

|                                     |  |
|-------------------------------------|--|
| <b>Load cell excitation Voltage</b> | DC 5V $\pm 5\%$ , 60mA<br>up to 4 x 350ohm load cells  |
| <b>Input sensitivity</b>            | 0.2 $\mu\text{V/D}$  |
| <b>System linearity</b>             | Within 0.01% F.S.  |
| <b>Zero adjust range</b>            | 0mV $\sim \pm 20\text{mV}$ ( $\pm 4\text{mV/V}$ )  |
| <b>Input Voltage</b>                | Max. 20mV    Min. 5mV  |
| <b>Accuracy</b>                     | Zero drift : $\pm 0.1\mu\text{V}/^\circ\text{C}$ RTI max.<br>Span drift : 20ppm/ $^\circ\text{C}$ max. |
| <b>Input Noise</b>                  | $\pm 0.3 \mu\text{V}$ p.p or less  |
| <b>Input Impedance</b>              | 10 $\text{M}\Omega$ (Min.)   |
| <b>A/D converter</b>                | Sigma-Delta system   |
| <b>A/D internal resolution</b>      | Approximately 200,000 counts   |
| <b>A/D external resolution</b>      | 1/20,000 (Max.)  |
| <b>A/D conversion speed</b>         | 10 times/sec   |
| <b>Max. resolution</b>              | 1/20,000   |

### 2. Digital Part

|                           |   |
|---------------------------|---|
| <b>Display</b>            | 7 Segment LED,<br>6-Digits, 14.22mm(Height) |
| <b>Maximum Display</b>    | -99999 $\sim$ +99999                        |
| <b>Display below zero</b> | "-" minus signal                            |
| <b>Additional symbols</b> | Zero, Stable, Net, Tare, Hold               |
| <b>Min. Division</b>      | 1, 2, 5, 10, 20, 50 selectable              |
| <b>Decimal Point</b>      | Selectable to any points                    |



### 3. Technical

|                              |   |
|------------------------------|---|
| <b>AC adapter</b>            | DC 9~12V<br>(AC 110/220V, DC 9V 1000mA Adapter) |
| <b>Power consumption</b>     | 1 VA  |
| <b>Operating temperature</b> | -10℃~+50℃                                       |
| <b>Humidity</b>              | 85% Rh Max.                                     |
| <b>Overall dimensions</b>    | 146(W) x 63(D) x 74(H)                          |
| <b>Weight</b>                | 800 g   |

### 4. Option


|                 |                            |
|-----------------|----------------------------|
| <b>Standard</b> | Serial Interface : RS-232C |
| <b>Option</b>   | Serial Interface : RS-485  |






# DIMENSIONS







## Front Panel

### 1. Display Lamp ( )



-  **ZERO lamp** : ON when the current weight is 0 kg.
-  **STABLE lamp** : ON when the weight is stable.
-  **NET lamp** : ON when the current weight is NET weight.
-  **TARE lamp** : ON when the tare weight is stored.
-  **HOLD lamp** : Lamp is on when moving object is weighed.

### 2. Keyboard

-  Available keys instead of numeric keys.  
Change the set value
-  Increases (Decrease) the first place value to 1.
-  Change the digit of the set value.  
Move to the right (left) by 1 place.
-  Usage-input the numeric value in CAL, SIM, SET mode.





Returns the display to 0



### - automatic tare weight input -

Use container in weighing.

Current weight is memorized as tare weight.

If you press TARE key in unload condition, Tare setting is released automatically.



### - manual tare weight input -

When you already know the tare weight, press key tare and input tare weight with arrow keys and memorize it by pressing ENTER key.




### - NET/GROSS Conversion -

Use container in weight.

NET lamp off – gross weight

NET lamp on –net weight

In case tare weight is registered, tare and item's total weight is G. weight and only item's weight is N. weight.



■ **Hold not used** → Set in F23 : 0

■ **Hold key** → Set in F23 : 1

■ **SET mode**

→ By pressing “ F/HOLD ” key more than 3 seconds.



■ **ENTER key**

→ Store current condition and exit.

### 3. How to enter SET mode

By pressing “ F/HOLD ” key more than 3 seconds.


### 4. How to enter CAL mode

Slid switch usage

■ **Dip slide SW 1 ON – CAL Mode**

■ **Dip slide SW 2 ON – SIM Mode**

## Rear Panel



■ **SERIAL OUTPUT** : Serial interface RS-232C & RS-485 port.

■ **POWER** : DC 9 ~ 12V

Use a stable power supply AC110/220V DC9V 1000mA

– Set up voltage AC220V

■ **LOAD CELL** : Please connect the indicator connector with the wire of load cell according to the color.

| Pin no. | SIGNAL                      |              |
|---------|-----------------------------|--------------|
| 1       | Load cell Input Voltage (+) | EXC+ (Red)   |
| 2       | Load cell Input Voltage (-) | EXC- (White) |
| 3       | Load cell output (+)        | SIG+ (Green) |
| 4       | Load cell output (-)        | SIG- (Blue)  |
| 5       | Shield                      | SHIELD       |


The wire color of load cell according to a manufactures.

|                 | 1<br>EXC+  | 2<br>EXC-    | 3<br>SIG+    | 4<br>SIG-   | 5<br>SHIELD   |
|-----------------|------------|--------------|--------------|-------------|---------------|
| <b>BONGSHIN</b> | <b>RED</b> | <b>WHITE</b> | <b>GREEN</b> | <b>BLUE</b> | <b>SHIELD</b> |
| CAS, TMI, AND   | RED        | WHITE        | GREEN        | BLUE        | SHIELD        |
| BLH             | GREEN      | BLACK        | WHITE        | RED         | YELLOW        |
| INTERFACE       | RED        | BLACK        | GREEN        | WHITE       | SHIELD        |
| KYOWA           | RED        | BLACK        | GREEN        | WHITE       | SHIELD        |
| P.T.            | RED        | BLACK        | GREEN        | WHITE       | SHIELD        |
| SHOWA           | RED        | BLUE         | WHITE        | BLACK       | SHIELD        |
| SHINKOH         | RED        | BLACK        | GREEN        | WHITE       | SHIELD        |
| TML             | RED        | BLACK        | WHITE        | GREEN       | SHIELD        |
| TFAC            | RED        | BLUE         | WHITE        | BLACK       | YELLOW        |
| HUNTLEIGH       | GREEN      | BLACK        | RED          | WHITE       | SHIELD        |

※ Because wire color may be different according to a manufacture and load cell models. Please refer for the data sheet of load cell.

## ■ CALIBRATION : Slid switch

### REAR SLIDE SWITCH USAGE



## ■ Dip slide sw 1 : CALIBRATION mode

SW 1 ON : Shift to calibration mode.

Turn sw1 off after calibration, It returns to weighing mode.


## ■ Dip slide sw 2 : SIMURATION CALIBRATION mode

SW 2 ON : Shift to simulation calibration mode.

Turn sw2 off after calibration, It returns to weighing mode.

## Calibration mode

### 1. How to Enter



Turn on the power while CAL switch 1 on the rear panel of the indicator and CAL mode starts.

### 2. Available Keys



Increase the first place set value to 1.



Move to the left by 1 place of the set value.



Move into next menu.

### 3. Calibration Menu (CAL 1 ~ CAL 5)

CAL 1 : Maximum Capacity Set

CAL 2 : Minimum Division Set

CAL 3 : Setting Weight in span calibration

CAL 4 : Zero Calibration

CAL 5 : Span Calibration

## ■ CAL 1

– Function : **Maximum Capacity Set**

Range → 1 ~ 99,999kg

| Key                           | Display | Description      |
|-------------------------------|---------|------------------|
| ▲▼ : Increase                 | CAL 1   | CAL 1 condition. |
| ◀▶ : Shift of digit           | C 100   | 100 kg           |
| “ENTER” key :                 | C 10000 | 10000kg          |
| Store and move into next menu |         |                  |

☞ REF 1. The maximum capacity means the maximum weight that scale can measure.

## ■ CAL 2

– Function : **Minimum Division Set**

Range → 1 ~ 50

| Key                           | Display | Description               |
|-------------------------------|---------|---------------------------|
| ▲▼ : Increase                 | CAL 2   | CAL 2 condition.          |
| “ENTER” key :                 | d 1     | 1 kg (Decimal point : 0)  |
| Store and move into next menu | d 1     | 0.01kg (Decimal point: 2) |

☞ REF 1. The minimum division means the value of one division.

☞ REF 2. External resolution is obtained by division the min. division by the maximum capacity. Set the resolution to be within 1/30,000.

## ■ CAL 3

– Function : **Setting Weight In Span Calibration**

Range → 1~ 99,999kg

| Key                           | Display | Description         |
|-------------------------------|---------|---------------------|
| ▲▼ : Increase                 | CAL 3   | CAL 3 “ENTER” key : |
| ◀▶ : Shift of digit           | L 100   | 100 kg              |
| “ENTER” key :                 | L 10000 | 10000kg             |
| Store and move into next menu |         | Setting Weight      |

☞ REF 1. The weight shall be within the range of 10%~100% of maximum weight.

☞ REF 2. The setting weight must be over the range of 10% of maximum weight.

☞ REF 3. The setting weight over the maximum capacity.

## ■ CAL 4

– Function : **Zero Calibration**

| Key              | Display   | Description                           |
|------------------|-----------|---------------------------------------|
| “ENTER” key :    | CAL 4     | CAL 4 condition.                      |
| Zero calibration | UnLoad    | Unload the tray and press “ENTER” key |
| and move into    | - - - - - | Under zero calibration                |
| next menu        | SUCCESS   | Zero calibration is completed.        |

☞ REF 1. If zero calibration is done without any error, “SUCCESS” message is displayed and program moves into CAL 5 automatically.

☞ REF 2. If the “ZERO” key is pressed, only zero calibration is completed and program moves SAVE & EXIT mode. Turn sw1 off.

## ■ CAL 5

– Function : **Span Calibration**

| Key  | Display  | Description  |
|--|--|--|
| <p>“ENTER” key :</p> <p>Span calibration and move into next menu</p> | <p>CAL 5</p> <p>LoAd</p> <p>-----</p> <p>SUCCESS</p> | <p>CAL 5 condition.</p> <p>Load the weight which was set in CAL3 and press “ENTER” key.</p> <p>Under span calibration</p> <p>Span calibration is completed.</p> <p>Turn sw1 off.</p> <p>(Save &amp; exit CAL mode)</p> <div data-bbox="708 657 952 828"> <p>1 2</p> <p>DIP S/W</p> <p>OFF</p> <p>ON</p> </div> |

☞ REF 1. If zero calibration is done without any error, “SUCCESS” message is displayed the weight of setting weight is displayed on LED screen.


Check the weight.

☞ REF 2. Check the weight of setting weight and turn sw1 off and calibration is completed.



## Simulation Calibration mode

### 1. How to Enter



Turn on the power while CAL switch 2 on the rear panel of the indicator and CAL mode starts.

### 2. Available Keys



Increase the first place set value to 1.



Move to the left by 1 place of the set value.



Move into next menu.

### 3. Calibration Menu (Sim 1 ~ Sim 4)

Sim 1 : Maximum Capacity Set

Sim 2 : Minimum Division Set

Sim 3 : Rated Output Set

Sim 4 : Zero Calibration

## ■ Sim 1

– Function : **Maximum Capacity Set**

Range → 1 ~ 99,999kg

| Key                           | Display         | Description      |
|-------------------------------|-----------------|------------------|
| ▲▼ : Increase                 | 5 1 $\bar{a}$ 1 | Sim 1 condition. |
| ◀▶ : Shift of digit           | L 100           | 100 kg           |
| “ENTER” key :                 | L 10000         | 10000kg          |
| Store and move into next menu |                 |                  |

☞ REF 1. The maximum capacity means the maximum weight that scale can measure.

## ■ Sim 2

– Function : **Minimum Division Set**

Range → 1~ 50

| Key                           | Display         | Description               |
|-------------------------------|-----------------|---------------------------|
| ▲▼ : Increase                 | 5 1 $\bar{a}$ 2 | Sim 2 condition.          |
| “ENTER” key :                 | d 1             | 1 kg (Decimal point : 0)  |
| Store and move into next menu | d 1             | 0.01kg (Decimal point: 2) |

☞ REF 1. The minimum division means the value of one division.

☞ REF 2. External resolution is obtained by division the min. division by the maximum capacity. Set the resolution to be within 1/20,000.

### ■ Sim 3

– Function : **Rated Output Set**

Range → 1mV/V ~ 3mV/V

| Key   | Display                                       | Description                                       |
|---|---|---|
| <p>▲▼ : Increase</p> <p>◀▶ : Shift of digit</p> <p>“ENTER” key :</p> <p>Store and move into next menu</p> | <p>5 1n 3</p> <p>r 1.0000</p> <p>r 2.0000</p> | <p>Sim 3 condition.</p> <p>1mV/V</p> <p>2mV/V</p> |

### ■ Sim 4

– Function : **Zero Calibration**

| 사용 키   | FND 화면  | 설 명  |
|--|---|--|
| <p>“ENTER” key :</p> <p>Zero calibration and move into next menu</p> | <p>5 1n 4</p> <p>UnLoAd</p> <p>- - - - -</p> <p>SUCCESS</p> | <p>Sim 4 condition.</p> <p>Unload the tray and press “ENTER” key</p> <p>Under zero calibration</p> <p>Zero calibration is completed &amp; Span calibration is completed. Turn sw2 off.</p> <p>(Save &amp; exit CAL mode).</p> <div data-bbox="678 1252 925 1425"> <p>1 2</p> <p>DIP S/W</p> <p>OFF ON</p> </div> |

- ☞ REF 1. If zero calibration is done without any error, "SUCCESS" message is displayed the weight of setting weight is displayed on LED screen.  
Check the weight.
- ☞ REF 2. Check the weight of setting weight and turn sw2 off and calibration is completed.

## 1. How to Enter

By pressing “ F/HOLD ” key more than 2 seconds.

At this time, “**F01**” message is displayed on FND screen after “**SET**” message.

- ① “**F01**” : Call the function which you want to convert.
- ② Input function no. to convert with arrow keys and press “**ENTER**” key.
- ③ “**F01-1**” : Means call the function which you would convert.
- ④ Input function no. to convert and press “**ENTER**” key.

## 2. How to Exit

By pressing “ F/HOLD ” key more than 2 seconds.


## 3. Available Keys



Increase the first place set value to 1.



Move to the left by 1 place of the set value.



SET mode starts.

Store current condition and SET mode exit.



Move into next menu.

## 4. Set Value Conversion Menu (F01~F33)

### ► General Function

- F01 Decimal Point Adjustment
- F02 Weighing Unit Change
- F03 Display Update Rate
- F04 Digital Filter
- F05 Motion Detection Condition
- F06 Automatic ZERO Tracking Compensation
- F07 Weight Backup
- F08 Set ZERO Range
- F09 ZERO & TARE Keys Availability
- F10 Set Hold Type
- F22 Device ID
- F23 Designation of “HOLD” key usage

### ► Serial Interface Setting

- F32 Designation of Baud Rate
- F33 Designation of Output Mode

### ► General Function

| Decimal Point Adjustment |   |                  |       |
|--------------------------|---|------------------|-------|
| <b>F01</b>               | 0 | No decimal point | 0     |
|                          | 1 | $10^1$           | 0.0   |
|                          | 2 | $10^2$           | 0.00  |
|                          | 3 | $10^3$           | 0.000 |

| Weighing Unit Change |   |    |          |
|----------------------|---|----|----------|
| <b>F02</b>           | 0 | g  | gram     |
|                      | 1 | kg | kilogram |
|                      | 2 | t  | ton      |
|                      | 3 | lb | pound    |


| Display Update Rate |   |              |
|---------------------|---|--------------|
| <b>F03</b>          | 0 | 10 Times/sec |
|                     | 1 | 5 Times/sec  |

| Digital Filter |   |                    |  |
|----------------|---|--------------------|--|
| <b>F04</b>     | 1 | 1 : Less vibration | Adjust the set value according to the condition how many times converted digital value read and display. |
|                | ~ | ~                  |  |
|                | 9 | 9 : Much vibration |  |
|                |   |                    |  |

| Motion Detection Condition |   |                               |  |
|----------------------------|---|-------------------------------|--|
| <b>F05</b>                 | 0 | No motion Detection Condition |  |
|                            | 1 | 1 : Less vibration            | If weight change within given time is not bigger than the SET range, stable condition is displayed.. |
|                            | ~ | ~                             |  |
|                            | 9 | 9 : Much vibration            |  |
|                            |   |                               |  |

| Automatic Zero Tracking Compensation |   |                     |   |
|--------------------------------------|---|---------------------|---|
| <b>F06</b>                           | 0 | None automatic zero |   |
|                                      | 1 | 1 : 0.5 digit       | Auto-zero tracking will automatically bring the display back to "0" when there are small deviations.. |
|                                      | 2 | 2 : 1 digit         |   |
|                                      | ~ | 3 : 1.5 digit       |   |
|                                      | 9 | 9 : 4.5 digit       |   |

| Weight Backup |   |   |
|---------------|---|---|
| <b>F07</b>    | 0 | Weight back-up is OFF (Power on zero)         |
|               | 1 | Weight back-up is ON (Display setting weight) |

 REF. Memorize the current weight at sudden power failure.

| Set Zero Range |   |                                   |
|----------------|---|-----------------------------------|
| <b>F08</b>     | 0 | 3% : within 3% of MAX. weight     |
|                | 1 | 10% : within 10% of MAX. weight   |
|                | 2 | 100% : within 100% of MAX. weight |

| Zero & Tare keys Availability |   |                             |
|-------------------------------|---|-----------------------------|
| <b>F09</b>                    | 0 | Works when weight is stable |
|                               | 1 | Always                      |

| Set Hold Type |   |  |
|---------------|---|--|
| <b>F10</b>    | 0 | Average Hold : Compute the average weight of oscillating weights.            |
|               | 1 | Peak Hold : Compute the maximum weight of oscillating weights.               |
|               | 2 | Instant Hold : The instant display value can now be held by pressing button. |

| Device ID  |    |                     |   |
|------------|----|---------------------|---|
| <b>F22</b> | 00 | 00 : Device ID "0"  | It is used the no. of indicator when system is connected. |
|            | ~  |                     |   |
|            | 99 | 99 : Device ID "99" |   |

| "PRINT" key usage |   |           |
|-------------------|---|-----------|
| <b>F23</b>        | 0 | Not used  |
|                   | 1 | Print key |
|                   | 2 | Hold key  |



**► RS-232C Interface Setting**

| Baud Rate  |   |                          |
|------------|---|--------------------------|
| <b>F32</b> | 0 | 600 bps (bit per second) |
|            | 1 | 1200 bps                 |
|            | 2 | 2400 bps                 |
|            | 3 | 4800 bps                 |
|            | 4 | 9600 bps                 |

| Output Mode (unit of speed in data transmission) |   |  |
|--|---|--|
| <b>F33</b>                                       | 0 | No data output   |
|  | 1 | Stream mode  |
|  | 2 | Transmit only in stable condition  |
|  | 3 | Transmit when data is required<br>→ Request signal : device ID(F22 : Device ID)<br>→ In case F22 : 1, send hex value 01H in computer |



## ② Header 2

- GS : GROSS WEIGHT MODE
- NT : NET WEIGHT MODE

## ③ Device ID

Transmit 1 byte device ID so that the receiver can receive data selectively which indicator send.

Insert in case of except SETUP F22-“00”

## ④ WEIGHT (8 byte)

- SIGNAL ( + or - )
  - WEIGHT ( Included Decimal point )
    - 100.0 kg : ‘0’, ‘0’, ‘0’, ‘1’, ‘0’, ‘0’, ‘.’, ‘0’,
    - 150.5 kg : ‘0’, ‘0’, ‘0’, ‘1’, ‘5’, ‘0’, ‘.’, ‘5’,
    - 165.3 kg : ‘-’, ‘0’, ‘0’, ‘1’, ‘6’, ‘5’, ‘.’, ‘3’,
- Each ASCII code of weight transmitted by 8 byte.( ‘0’ : 0 x 20)



## ⑤ Data for Number

- 2B(H) “ + ” : PLUS
- 2D(H) “ - ” : MINUS
- 2O(H) “ ” : SPACE
- 2E(H) “ . ” : Decimal Point

## ⑥ Unit

- g : Unit of gram
- kg : Unit of kilogram
- t : Unit of ton
- lb : Unit of pound

### ► RS-232C port connection



## ► Simple Interface Program

### ■ Basic Program

```

10 OPEN "COM1:9600,N,8,1" As #1
20 IF LOC(1) = 0 THEN 60
30 A$ = INPUT$(1,1)
40 PRINT A$ ; " ";
50 GOTO 20
60 B$=INKEY$ : IF B$ = " " THEN 20
70 PRINT B$ ; " ";
80 PRINT #1,B$;
90 GOTO 20

```

### ■ C Program

```

#include <bios.h>
#include <conio.h>
#define COM1          0
#define DATA_READY  0×100
#define TRUE          1
#define FALSE         0
#define SETTINGS      0×E3
int main(void)
{
    int in, out, status, DONE = FALSE;
    bioscom(0, SETTINGS, COM1);
    cprintf("...BIOSCOM [ESC] to exit ...Wn");
    while (!DONE)
    {

```

```
status = bioscom(3, 0, COM1);  
if (status & DATA_READY)  
    if ((out = bioscom(2, 0, COM1) & 0×7F) != 0)  
        putchar(out);  
    if (kbhit())  
    {  
        if ((in = getch()) == 'W×1B')  
            DONE = TRUE;  
        bioscom(1, in, COM1);  
    }  
}  
return 0;  
}
```



# Error Message and Trouble Shooting

## 1. Error in Weighing Mode

### ■ no LC

#### Reason

Failure in load cell connection or error in A/D conversion part.

#### Trouble shooting

Check the load cell connector so that you may see if the polarity of signal is reversed.

### ■ Over

#### Reason

The weight on platform is too heavy to be measured.

#### Trouble shooting

Do not load the item exceeds the maximum tolerance.

If the load cell is damaged, the load cell should be replaced.

### ■ BUZZER

#### Reason

Current weight deviates from zero range.

#### Trouble shooting

Press the ZERO key within 10% of the maximum capacity.

(Function : F11 – x)



## 2. Error in Calibration Mode

### ■ no LC , no 1

#### Reason

Failure in load cell connection or error in A/D conversion part.

#### Trouble shooting

Check the load cell connector so that you may see if the polarity of signal is reversed.

### ■ Over

#### Reason

The weight on platform is too heavy to be measured.

The weight for span calibration is set to be exceeded 100% of the maximum capacity of the scale.

#### Trouble shooting

Do not load the item exceeds the maximum tolerance.

If the load cell is damaged, the load cell should be replaced.

Set the weight for span calibration is set to be within the maximum capacity of the scale in CAL 1.